

(English)

Operating Instructions

Multifunctional OLED Display

The T4K is equipped with a multifunctional OLED display. (Please remove the screen protector before the first use.) When the light is turned on, the screen will successively show the current info (Brightness Level & Lumens, Runtime Remaining, User Mode) before it goes out. After the screen goes out, short pressing the Mode Button can reactivate the screen.

Display Demonstration Function

- This function is used for demonstration ONLY. It does not reflect the actual light status.
- When the light is off, keep holding the Power Button even after ULTRALOW is accessed until the light is turned off to enter the display demonstration.
- In this status, the screen will cycle through various informational displays. Short press either button to exit this status.

On / Off

On: When the light is off, short press the Power Button to turn it on. Off: When the light is on, short press the Power Button to turn it off.

User Modes

The T4K has 2 user modes, DEMO Mode and DAILY Mode. **DEMO Mode:** The light will automatically shut down if there is no operation in 30 seconds (reactivating the screen excluded). The countdown will be displayed on the screen.

DAILY Mode: The light will not automatically shut down and will need to be shut down manually.

Note: The default setting is DEMO Mode. It is recommended to switch it to DAILY Mode when in daily use.

Mode Switching

When the light is on/off, long press both the Power Button and the Mode Button simultaneously to switch between DEMO and DAILY Mode. The LEDs will flash to indicate the current user mode: 1 flash to indicate DEMO Mode and 2 flashes to indicate DAILY Mode. (In this process, the screen will show "DEMO" or "DAILY" to indicate the current user mode.)

Note: Reactivating the light within 3 seconds after it automatically shuts down in DEMO mode will temporarily access DAILY Mode until it is turned off.

Brightness Levels

When the light and the screen is on, short press the Mode Button to cycle through the following brightness levels: ULTRALOW - LOW - MID - HIGH. The flashlight will directly access the previously memorized brightness level when reactivated.

Note: When the screen is off, short press the Mode Button to activate the screen before adjusting the brightness level.

Direct Access to ULTRALOW

When the light is off, long press the Power Button to directly access ULTRALOW.

Direct Access to TURBO

When the light is on/off, press and hold the Mode Button to access TURBO. Release to return to the previous status.

Note:

- When activating TURBO, a countdown progress bar will be shown on the display to indicate the activation time for TURBO after showing the current brightness level and lumens.
- When activating the Mode button after the progress bar is deleted, the flashlight will access HIGH Level instead and the display will turn off.
- The activation time for TURBO depends on the thermal status of the flashlight. The higher the temperature of the flashlight, the shorter the activation time for TURBO when it is reactivated.
- Use caution when operating the light in TURBO to avoid overheating and step down to a lower level if the light becomes too hot to handle.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.
- When in Half Lockout Mode, the Power Button is unavailable for activating the flashlight. Holding the Mode Button is still available for accessing TURBO.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.
- When in Full Lockout Mode, both buttons are unavailable to activate the flashlight.
- Unlock:**
 - In either Lockout Mode, short press and then long press the Power Button, during which the screen will show an unlock icon and a progress bar, until the flashlight is activated to Half Lockout Mode.
 - When in Full Lockout Mode, both buttons are unavailable to activate the flashlight.

Lockout

- In either Lockout Mode, short press and then long press the Power Button, during which the screen will show an unlock icon and a progress bar, until the flashlight is activated to Half Lockout Mode.
- When in Full Lockout Mode, both buttons are unavailable to activate the flashlight.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

Full Lockout Mode (Lockout 2):

- When the light is on, keep holding the Power Button even after accessing Half Lockout Mode until the screen shows Lockout 2 icon. The light will turn off and access Full Lockout Mode.

Lockout / Unlock

① (Half Lockout Mode) ② (Full Lockout Mode) |

The T4K has two lockout modes (Half Lockout Mode and Full Lockout Mode).

Half Lockout Mode (Lockout 1):

- When the light is on, press and hold the Power Button until the screen shows the Lockout 1 icon. The light will turn off and access Half Lockout Mode.

