

The All-Round Flashlight Expert

MT2UA User Manual

Features

- Utilizes a CREE XP-G2 R5 LED
- · Maximum output of 360 lumens
- · Integrated "Precision Digital Optics Technology" provides extreme reflector performance

Boasts a peak beam intensity of 6,500 cd and a throw distance up to 160 meters

- Tail switch designed for tactical applications
 Side switches for selecting brightness levels or modes
- Features intelligent memory effect
- Red LED provides constant/flashing illumination
 Displays battery voltage with red light (accurate to 0.1V)
- High efficiency constant current circuit enables maximum runtime of 180 hours
- Direct access to turbo/red light mode
 Reverse polarity protection prevents damage from incorrectly inserted batteries
- · Stainless steel titanium-plated two-way clip
- Toughened ultra-clear mineral glass with anti-reflective coating
 Robust HAIII military grade hard-anodized
- Waterproof in accordance with IPX-8 (two-meter submersible)
- · Tail stand capability

Dimensions

Accessories

Quality holster, clip, lanyard, spare tail cap cover, spare O-ring

Length: 6.18" (156.9mm) Head Diameter: 1" (25.4mm) Tail Diameter: 0.85"(21.5mm) Weight: 2.65oz (75g)(without battery)

Battery Options	Туре	Nominal voltage	Compatible	
Primary AA battery	AA	1.5V	Y (Recommended)	
Rechargeable AA battery	AA 1.2V Y (R		Y (Recommended)	
Primary AA Lithium battery	L91	1.5V	Y (Recommended)	
Primary LiFePO4 battery	14500	3.2V	N (Banned)	
Rechargeable Li-ion battery	14500	3.7V	N (Banned)	

Brightness & Runtime

Brightness & Runtine							
FL1 STANDARD	TURBO	HIGH	MID	LOW	LOWER		
31/5	360 LUMENS	240 LUMENS	120 LUMENS	17 LUMENS	1 LUMEN		
0	1h45min	2h15min	5h45min	24h	180h		
	160m (Beam Distance)						
	6500cd (Peak Beam Intensity)						
V	1.5m (Impact Resistant)						
T	IPX-8, 2m (Waterproof and Submersible)						

The stated data has been measured in accordance with the international flashlight testing standards ANSI/NEMA FL1, using two high quality AA rechargeable batteries (1.2V 2500mAH) under laboratory conditions. The data may vary in real-world use due to different battery usage or environmental conditions.

Operating Instructions

Battery Installation

Insert two AA batteries as illustrated. WARNING:

Ensure batteries are inserted with the positive (+) end pointing towards the head. The MT20A will not be operational with incorrectly inserted batteries.

Momentary Illumination

Momentary illumination can be achieved by switching the flashlight off and then half pressing and holding the tail switch. Release switch to turn the light off.

Switching ON/OFF

Switch ON: Press the button on the tailcap all the way down until a "click" is heard. Switch OFF: Press the button on the tailcap all the way down until a "click" is heard. Standby Mode:

When power is off, press both side switches simultaneously to activate the red power indicator to flash and indicate battery voltage. Three seconds after electrical voltage is reported, the MT20A enters standby mode where the indicator flashes once every three seconds. In standby mode, the MT20A will operate for approximately 60 days with the indicator on.

Brightness Levels

When the MT20A is switched on, press the step-up switch repeatedly to switch among the following brightness levels: red beacon-red light-ultralow-low-medium-high-turbo. The MT20A has memory effect. When it is switched on, the MT20A will enter the brightness

When the MT20A is switched on, press the step-down switch repeatedly to level down its brightness until it reaches red beacon mode, after which there is no cycling back to other brightness levels.

Direct Access to Red Light Mode:

When the MT20A is switched on, press and hold the step-down switch for over one second to access red light mode: OR:

When the MT20A is switched off, press and hold the step-down switch while the tailcap button is being held simultaneously to access the red light mode.

Direct Access to Turbo:

When the MT20A is switched on, press and hold the step-up switch for over one second to access turbo output (360 lumens); OR:

When the MT20A is switched off, press and hold the step-up switch and press the

button on the tailcap to access turbo output (360 lumens).

Note: After three minutes' using of turbo mode, the flashlight will lower its output automatically for preventing overheating, and efficiently ensure the battery runtime.

Special Modes (Strobe/Location Beacon/SOS)

With the light switched on, press both side switches to enter strobe mode. When in with the light switched on, press both side switches less to be mode, to enter strobe mode. When it strobe mode, press both side switches less again to cycle through Location Beacon, SOS, and Strobe modes. To exit and resume the brightness level last used, simply press the step-up or step-down switch. The MT20A has memory effect in strobe mode. If it is turned off in strobe mode, it will enter strobe mode immediately when switched on

Power Tips

With the light switched off, press both side switches and the button on the tailcap to activate the red power indicator to blink and indicate battery voltage (accurate to ±0.1V). For example, when battery voltage is at 2.4V, the red power indicator will blink 2 times, followed by a one second pause and another 4 blinks. Different voltages represent the corresponding remaining battery power levels.

Changing / Charging Battery

Batteries should be replaced or recharged when output appears to be dim or the flashlight becomes unresponsive.

Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

Warranty Service

All NITECORE® products are warranted for quality. Any defective / malfunctioning NITECORE® product can be repaired free of charge for a period of 60 months (5 years) from the date of purchase. Beyond 60 months (5 years), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified in all of the following situations:

- 1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized
- parties.
 2. The product(s) is/are damaged through improper use.
- 3. The product(s) is/are damaged by leakage of batteries.

For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to service@nitecore.com

XAII images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occurs between this manual and information specified on www.nitecore.com, information on our official website shall prevail. Sysmax Industry Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.



III Please find us on facebook: NITECORE Flashlights



SYSMAX Industry Co., Ltd. +86-20-83862000 TEL: +86-20-83882723 FAX: E-mail: info@nitecore.com Web: www.nitecore.com

Address Rm1401-03, Glorious Tower, 850 East Dongfeng Road,

Guangzhou, China 510600

